

# BD Rowa™ Vmax/Smart

## Daily use

### ① Turn on the machine

- 1 Turn the main switch to the **on** position.
- 2 Wait until the screen displays the message **Push the start button** in the top-left corner.
- 3 Push the start button.

### Input packs

- 1 Select **Stock input**.
- 2 Select **New delivery** or **Stock return**.
- 3 Input the expiry date by clicking the **Expiry date** button.
- 4 Select optional modes, if required:

- Cubic / round
- Opened pack
- Multi-mode

**When using multi-mode, make sure all packs have the same product code and expiry date.**

- 5 Scan the barcode of the pack.
- 6 When inputting an opened pack: enter the remaining doses in the pack on the screen.
- 7 Place the pack on the input belt in the correct position.

**If the robot doesn't accept the pack, a message with more information will appear on the monitor.**

### Stock level / stock output

**To output a product or to check the stock levels of each product:**

- 1 Select **Stock Level / Stock Output** > **Article overview**.
- 2 Use the search box to look for a specific product, select the desired number of packs and output them.

**To manage the stock in the machine:**

- 1 Select **Stock Level / Stock Output** > **Stock maintenance**.
- 2 Use the button **Fast filter** to switch the view between **Expiry dates**, **Unused packs**, and **Orders**.

### ② Shut down the machine

**The machine should be shut down at least once per week.**

- 1 Click the **power icon** on the screen.
- 2 Select **Shut down machine**.
- 3 Wait until the screen turns black.
- 4 Turn the main switch to the **off** position.
- 5 Leave the machine turned off for a minimum of **5 minutes**.

**This process needs to be repeated for each system and component.**



**Want to learn more?**  
Visit the BD Rowa™ Customer Learning Center at <https://clc.rowa.de>.

If you have any questions, please contact BD Rowa™ Service.

This document does not replace the operating instructions. The contents of the operating instructions must be read carefully and followed!

[bd.com/rowa](https://bd.com/rowa)

BD, the BD Logo, Rowa, Smart and Vmax are trademarks of Becton, Dickinson and Company or its affiliates. All other trademarks are the property of their respective owners. © 2024 BD. All rights reserved. (Jan-2024 NPM-3310)

