

BD Rowa™ Vmax/Smart

Housekeeping checklist

Stock maintenance

Task	Recommendation	Responsible
Check expired stock	Monthly	
Check unused stock	Monthly	
Stock comparison to pharmacy IT system	Daily, min. weekly	

Maintenance

Task	Recommendation	Responsible
Resolve errors	Daily	
Reboot the robot	Min. weekly	
Scan shelves	Monthly or when necessary	
Check the grip tape	Monthly	
Check spare kit	Monthly	

Cleaning

Task	Recommendation	Responsible
Clean the sensors	Weekly	
Clean the spindle	Every 4 months	
Vacuum the carpet	Every 4 months	
Clean the shelves	With cleaning module: every 6 months Without cleaning module: once per year	

Notes



Want to learn more?
Visit the BD Rowa™ Customer Learning Center at <https://clc.rowa.de>.

If you have any questions, please contact BD Rowa™ Service.

This document does not replace the operating instructions. The contents of the operating instructions must be read carefully and followed!

bd.com/rowa

BD, the BD Logo, Rowa, Smart and Vmax are trademarks of Becton, Dickinson and Company or its affiliates. All other trademarks are the property of their respective owners. © 2024 BD. All rights reserved. (Jan-2024 NPM-3312)

